

Protect & Beautify Your Pool with

DRYLOK® EXTREME (FOR MASONRY POOLS ONLY)

UNITED GILSONITE LABORATORIES

P.O. BOX 70 • SCRANTON, PA • Phone 570-344-1202 • Toll Free 800-UGL-LABS • Fax 570-969-7634

www.drylok.com



DRYLOK® EXTREME Masonry Waterproofer is the perfect way to keep your swimming pool looking great. DRYLOK penetrates through the pores of masonry, acting as a barrier against water seepage. Specially formulated to resist mildew growth, with the incorporation of a green biocide, on the paint film. DRYLOK is great for masonry swimming pools and fountains. Anywhere water and masonry meet.

Surface Preparation

Apply DRYLOK over bare masonry only. Do not apply DRYLOK over any other pool coating. Drain all water from the pool and remove all surface contaminants from pool floor and walls. Be sure to remove any hydrostatic relief plugs. Scrape all old, loose materials off the pool surface. A high pressure power washer or sandblasting will help. Chip out any divots, loose cement, holes, cracks or deteriorating seams and patch with DRYLOK® Fast Plug® Hydraulic



Cement. Smooth the patch evenly with the surrounding surface. Remove all efflorescence (white, crystal-like salt deposits that form on masonry surfaces) with DRYLOK Etch, carefully following all instruction on the label. After etching, rinse treated surfaces thoroughly with clean water. Allow pool surface to dry thoroughly before applying the first coat of DRYLOK Extreme Masonry Waterproofing.



Application

Carefully follow all instructions on the label. Apply DRYLOK over bare masonry only. Do not apply DRYLOK over any other pool coating. DRYLOK works best when applied over a dry surface. DRYLOK should not be applied when air and surface temperature is less than 50°F or if temperature is expected to drop below 50°F within 24 hours. Stir DRYLOK Extreme thoroughly before and during application. DRYLOK may be applied by brush, roller or spray. Apply DRYLOK directly on bare masonry at a rate of

75-100 square feet per gallon. Two coats of DRYLOK Extreme must be applied. Apply the first coat with a roller (3/4" nap), or a brush working the waterproofing into the pores of the masonry, making sure all voids and pin holes are filled. Allow the first coat of DRYLOK to dry for 3 hours and apply second coat. The second coat may be applied by brush, roller or spray. Spray specifications are available on DRYLOK's web site at www.drylok.com. Important: After applying the second coat of DRYLOK Extreme Masonry Waterproofing, carefully inspect the entire wall surface for any pin holes in the waterproof coating. Any affected area should be painted with an additional coat to ensure satisfactory waterproofing results. Allow DRYLOK Extreme Masonry Waterproofing to dry at least one week before filling pool and adding chemicals.

DRYLOK®
A SIKA BRAND